


From the Frame Up, LLC



Tech Tips:

AC142 – Bonnet Support Photos & Installation

The installation of the bonnet props is accomplished by removing the top corner bolt on your bulkhead and then replacing it with the bonnet prop support bracket under the head of the bolt. The bracket is provided with a light coat of cad colored paint. However, the best finish is to paint the bracket body color to blend and remain unnoticeable.



Once the bracket is installed simply raise the bonnet and place the “nut” end of the rod in the bracket and the rubber ball inside the round spring associated with the bonnet latch.

Note: Be cautious about leaving your bonnet up in any windy conditions as damage might occur with any wind gust.

Thank you for your purchase! FTFU

Safety Fast!

© Copyright 2008, From The Frame Up, LLC

www.FromTheFrameUp.com

Please refer comments or questions to: Info@FromTheFrameUp.com