


Tech Tips:


CR182 – TB/TC Gas Cap Assembly

The assembly of the gas cap can often be somewhat confusing as there are a number of components in the cap itself. The following photo illustrates each of these items and are numbered to show the proper assembly order.



Item #	Description	Photo
CR182a	Gas cap only, no internals	# 1
CR182b	Stud, gas cap	# 2
SPG052	Flat clip spring, gas cap	# 3
SPG054	Coil spring, gas cap	# 4
CR182c	Slotted main disc, gas cap	# 5
CR182d	Spacer, gas cap	# 6
GA234	Fuel cap paper gasket	# 7
CR182e	Ribbed washer, gas cap	# 8
WASP031	Washer, shake proof	# 9
NTPBA2b	Nut, brass	# 10
SP0608	Cotter pin, gas cap to tank	# 11

The fully assembled cap will look like this:



SAFETY FAST!